

### savvy overview

- - - Device Group
- . . . savvyPanel System
- - - Example

#### Directory

Discover devices when **savvy** launches or by using the Directory Menu.

Discover by; Group, **savvyPanel** System, Discovery file, remote IP address or all local devices automatically or by request.

#### Function Block Engine

With standard **savvy**, the Device Overview screen gives access to Comms Server setup, Function Block Engine and native device functions where applicable.

With **savvy-SFD** place function blocks graphically, use function block list to review and arrange execution order.

#### Function Block


View functional elements and signal paths in relation to parameters.

Parameters show type, **drive.web** connections, read-only and not at default adornments.


#### Parameter Dock

Add parameters of interest to set, view, create trend graphs and export .csv files for spreadsheets.

Save Docks and open multiple Docks in different viewer windows.



### savvyPanel overview



#### Systems Page

View all available **savvyPanel** Systems. Assign a **savvyPanel** System in each device's contextual menu, one per device. If a **savvyPanel** Password is set in the device, it must also be added in **savvyPanel** operator station software under the **savvyPanel** menu

#### Home Page

The master page for a **savvyPanel** System. Similar to Operator Pages except that it may be accessed by pressing the Navigate Up arrow from any Operator Page. Graphic tiles can be touch-linked to Operator Pages.

#### Operator Pages

Up to 256 possible. May be page-linked in any way. Set **savvy** Preferences so that Operators view a specific page at launch. Use this Preference and the Home Password to restrict access to the Home Page and pages linked only from the Home Page. Provide links to the Home Page to bypass the Home Password. Home Password then only restricts access to the System Page.